



Nosecone marking guide: Cut and join two pieces of scrap lumber at 90 degrees. Drill small hole in lower piece for nosecone tip to rest in. Drill second hole in side piece at height where line is to be drawn, then friction fit pencil.

Once the line is drawn on the nosecone, it is then very easy to wrap narrow (eg, 1/4") masking tape along the line for painting two tone nosecones such as the Estes Big Daddy.

